



(GB) WHEEL SET (P/N 9222)

The Wheel Set will make your cultivator and all of the attachments more versatile. Allows you to park your tiller in a freestanding upright position for fueling and storage. The Wheel Set is extremely useful when using the Border Edger and Crevice Cleaner. Also it gives you the option of rolling your tiller to the garden.

(DE) RÄDER (Art. No. 9222)

Mit den Rädern lassen sich die Fräse und die anderen Zubehörteile noch besser einsetzen. Mit den Rädern können Sie das Gerät zum Beispiel parken, was das Betanken und die Lagerung im Winter enorm vereinfacht. Die Räder erleichtern außerdem die Arbeit mit dem Kantenschneider und dem Fugenreiniger. Und schließlich lässt sich das Gerät einfacher in den Garten transportieren.

(FR) JEU DE ROUES (Article N° 9222)

Le jeu de roues multiplie les usages de la motobèche et de ses accessoires. Grâce aux roues, la motobèche tient toute seule en position verticale pour permettre de faire le plein de carburant et pour le rangement. Le jeu de roues est particulièrement utile avec l'accessoire pour bordures et la nettoyeuse de crevasses. Grâce aux roues, vous pouvez également faire rouler la motobèche jusqu'au jardin.

(IT) GRUPPO DELLE RUOTE (Articolo n. 9222)

Il gruppo delle ruote rende più versatile il dissodatore e tutti i suoi attrezzi. Permette inoltre di parcheggiare il dissodatore in posizione diritta ai fini del rifornimento del carburante e della conservazione della macchina. Il gruppo delle ruote è estremamente utile se si usa il dissodatore e la pulitrice per fessure. Inoltre, permette di trasportare il dissodatore in giardino senza doverlo sollevare.

(NL) WIELENSET (Cat. nr. 9222)

De wielenset zal de cultivator en alle hulpstukken veelzijdiger maken. Hiermee kunt u de grondbewerker in een vrijstaande stand recht overeind zetten voor het bijvullen met brandstof en het opslaan. De wielenset is uiterst handig wanneer u de randtrimmer en voegenreiniger gebruikt. Ook heeft u hiermee de optie om de grondbewerker naar de tuin te rollen.

(PT) JOGO DE RODAS (P/N 9222)

O Jogo de Rodas transforma a sua cultivadora e todos os seus acessórios num equipamento mais versátil. Permite-lhe parar a sua cultivadora numa posição vertical, sem apoio, o que facilita o abastecimento de combustível e a armazenagem. O Jogo de Rodas é particularmente útil com o acessório para Orlas/Bordas e com o Limpador de Fendas. Graças a este jogo de rodas poderá ainda rolar a sua cultivadora para a levar até ao jardim.

(ES) JUEGO DE RUEDAS (Cat. # 9222)

El juego de ruedas hará de su cultivadora un equipo más versátil así como a todos los aditamentos adicionales. Le permitirá colocar su excavadora en una posición vertical y apoyada en sí misma, para las funciones de llenado de combustible y almacenamiento. El juego de ruedas es extremadamente útil cuando se usa la orilladora Border Edger y la cepilladora de grietas. Este juego de ruedas también le ofrece la opción de desplazar rodando su excavadora por el prado.

GB

WHEEL SET

All attachments mount on the tine shafts and are held in place with retaining pins. Attachment maintenance is very simple. Just clean with your garden hose. When dry, spray with a light pressurized oil like WD40.

Note:

In the instructions that follow, assume that you are standing behind the Tiller as you would in tilling or cultivating.

OPERATING INSTRUCTIONS AND PARTS LISTS


How to Assemble & Mount

Gently lay tiller down on the front side – to stabilize it.

1. Using a pair of 7/16" wrenches, remove 2 nuts, bolts and brackets from lower handles of tiller, set aside. The brackets will be replaced by the ends of the Wheel Set Bracket.
2. Slide Transmission Bracket (P/N 449) onto lower tiller handles above tiller hood. The fit will be tight. Note arrow (↑) pointing toward top on bracket.

Note: Be sure the channel in the Wheel Set Bracket points down and away from the back of the tiller. This will insure that the wheels will not contact the tines (see Photo above).

3. Fasten Transmission Bracket (P/N 449) with nuts (P/N 972) and bolts (P/N 4049) provided in Wheel Kit.



4. Using shoulder bolts (P/N 497) provided, attach wheels (P/N 491) to wheel bracket. Place bolts into the wheels and tighten into weld nuts on the Wheel Bracket (P/N 448).
5. Insert Wheel Bracket into the channel of the Transmission Bracket. (The Wheel Bracket fits loosely in the channel to allow adjustment of height.)
6. Insert pin into proper hole for desired height.

Suggested Uses

- Park your tiller in a freestanding, upright position for fueling and storage.
- Roll your tiller to your garden for added ease.
- Use in concert with your other Tiller attachment for increased stability.
- Multiple settings to insure precise depth control.

WHEEL SET CAT. #9222

ATTACHMENT LIMITED SERVICE & WARRANTY POLICY

The Mantis Tiller and its attachments are guaranteed against defects in material and workmanship for a period of TWO YEARS FROM DATE OF PURCHASE. All tines for the tiller are guaranteed for five years against breakage. Any Mantis products or parts found to be defective within the warranty period are to be returned to our factory listed below.

Transportation charges on parts and units submitted for replacement under this warranty must be borne by the purchaser.

THIS WARRANTY shall not be effective if the product has been the subject of misuse, negligence or accident or if the product has been repaired or altered outside of our factory in any respect which affects its condition or operation.

Mantis shall not be liable for any special indirect or consequential damages arising from defective equipment. Any implied warranty, including merchantability or fitness for a particular purpose, shall not extend beyond the written warranty period.

TINE GUARANTEE

Our tines not only work better than the rest; they're also guaranteed for five years against breakage. If any tine ever breaks in normal use, send the broken tine back to us and we'll send you a replacement tine FREE!



WARNING • DANGER
IMPROPER USE OR CARE OF THESE ATTACHMENTS OR FAILURE TO WEAR PROPER PROTECTION CAN RESULT IN SERIOUS INJURY.

READ AND UNDERSTAND THE RULES FOR SAFE OPERATION AND ALL INSTRUCTIONS IN THIS MANUAL.

WEAR HEARING AND EYE PROTECTION.

Warnings - dos

Read and understand the owner's manual. Pay particular attention to all sections regarding safety.

1. Always keep a firm grip on both handles while the attachment is moving and/or the engine is running. BE AWARE!! The tines may coast after throttle trigger is released. make sure tines have come to a complete stop and engine is off before letting go of the tiller.

2. Always maintain a firm footing and good balance, do not overreach while operating the tiller. Before you start to use the tiller check the work area for obstacles that might cause you to lose your footing, balance or control of the machine.

3. Always keep area clear of children, pets and bystanders.

4. Always stay alert. Watch what you are doing and use common sense. Do not operate unit when fatigued.

5. Always dress properly. Do not wear loose clothing or jewellery, they might get caught in moving parts. Use sturdy gloves. Gloves reduce the transmission of vibration to your hands. Prolonged exposure to vibration can cause numbness and other ailments. Wear non-skid foot wear to ensure secure and proper footing.

6. Always wear ear and eye protection. Eye protection must meet applicable CE standards. To avoid hearing damage we recommend hearing protection be worn whenever using the equipment.

7. Always keep a safe distance between two or more people when working together.

8. Always inspect your attachment before each use and ensure that all handles, guards and fasteners are secure, operating and in place.

Always maintain and examine your tiller and attachments with care. Follow maintenance instructions given in tiller manual.

10. Always store attachments in a sheltered area (a dry place) not accessible to children. The tiller as well as fuel should not be stored in a house.

Warnings - don'ts

Don't use tiller with one hand, keep both hands on handles with fingers and thumbs encircling the handles, while attachment is moving, and engine is running.

Don't overreach. Keep a good footing at all times.

Don't attempt to clear attachment while it is moving. Never try to remove jammed material before switching the engine off and making sure the attachment has stopped completely.

Don't allow children or incapable people to operate the tiller.

Don't operate while under the influence of alcohol or drugs.

Don't attempt to repair the attachment. Have repairs made by a qualified dealer or repairman. See that only original Mantis parts are used.

WARNING • DANGER

HANDLE FUEL WITH CARE, IT IS HIGHLY FLAMMABLE. FUELING A HOT ENGINE OR NEAR AN IGNITION SOURCE CAN CAUSE A FIRE AND RESULT IN SERIOUS PERSONAL INJURY AND/OR PROPERTY DAMAGE.

Engine fuel warnings - do's

Always use fresh petrol in the fuel mixture. Stale petrol can cause leakage.

Always pull starter cord slowly until resistance is felt. Then pull cord rapidly to avoid kickback and prevent arm or hand injury.

Always operate engine with spark arrestor installed and operating properly.

Engine/fuel warnings - don'ts

Don't fuel, refuel or check fuel while smoking or near an open flame or other ignition source. Stop engine and be sure it is cool before refueling.

Don't leave the engine running while the tiller is unattended. Stop engine before putting the tiller down or while transporting from one place to another.

Don't refuel, start or run this tiller indoors or in an improperly ventilated area.

Don't run engine when electrical system causes spark outside the cylinder. During periodical checks of the spark plug, keep

plug a safe distance from cylinder to avoid burning of evaporated fuel from cylinder.

Don't check for spark with spark plug or plug wire removed. use an approved tester.

Don't crank engine with spark plug removed, except when preparing to store tiller for the off season.

Don't run engine when the odor of petrol is present or other explosive conditions exist.

Don't operate the unit if petrol is spilled. Clean up spill completely before starting engine.

Don't operate your tiller if there is an accumulation of debris around the exhaust and cooling fins.

Don't touch hot exhaust, cylinders or cooling fins as contact may cause serious burns.